
BENDIT

Accessories - Q-CAP Flexible Fixtures

5 YEAR WARRANTY



- Flexible metal channels offer secure support for any Q-CAP product.
- Can be screwed into surfaces to hold fixtures in the exact position you require, even when mixing profiles to create compound curves
- Mounts onto surfaces via self-tapping flat head screws
  64 #4×1/2" Tapping Screws provided per 16'
- Sold in 16' or 32' rolls
- Field cuttable
- Indoor/outdoor use
- Channels bend in one direction, either up/down or side-to-side
- BENDIT channels are made out of stainless steel
- Uncoated: low cost, best for indirect view
- White finish: blends with the Q-CAP housing, best for direct view
- Black finish: Blends with KURV-BK's black housing

1 PRODUCT & BEND DIRECTION	2 COLOR	3 LENGTH (FT)

Sample Part Number: **STND-QCAP-BN-UD-SST-16'**

1 PRODUCT & BEND DIRECTION

STND-QCAP-BN-UD	Up/Down Bend | Compatible with BOXA
STND-QCAP-BN-UD-S	Up/Down Bend | Compatible with WURM
MICRO5-BN-UD	Up/Down Bend | Compatible with ANYBEND & WAVE
MICRO5-BN-UD-S	Up/Down Bend | Compatible with NEXUS
STND-QCAP-BN-SB	Side Bend | Compatible with KURV & ZALA
MICRO5-BN-SB	Side Bend | Compatible with ANYBEND & WALA
STND-QCAP-BN-SB-W	Side Bend | Compatible with KURV-BK

2 COLOR

SST	Stainless Steel
WH	White Powder Coated Stainless Steel
BK	Black Powder Coated Stainless Steel

3 LENGTH (FT)

16'
32'

5 year warranty | Data subject to change, all data has +/- 5% tolerance

© 2025 QTL. All rights reserved | 155 Hill St. Milford, CT 06460 | 203-367-8777 | sales@QTL.lighting | QTL.lighting

Specification subject to change. Rev-03-11-25


BENDIT

Accessories - Q-CAP Flexible Fixtures

1 PRODUCT - DIMENSIONS

UP/DOWN BEND

STND-QCAP-BN-UD




BENDIT Channel
Vertical Stainless Steel
Flexible Channel

Continuous mounting solution for flexible fixtures, 16' or 32' field cuttable lengths

64 #4-40 1/2" screws provided per 16'

Compatible with
BOXA

STND-QCAP-BN-UD-S




BENDIT Channel
Vertical Stainless Steel
Flexible Channel

Continuous mounting solution for flexible fixtures, 16' or 32' field cuttable lengths

64 #4-40 1/2" screws provided per 16'

Compatible with
WURM

MICRO5-BN-UD




BENDIT Channel
Vertical Stainless Steel
Flexible Channel

Continuous mounting solution for flexible fixtures, 16' or 32' field cuttable lengths

64 #4-40 1/2" screws provided per 16'

Compatible with
ANYBEND
WAVE

MICRO5-BN-UD-S



BENDIT Channel
Vertical Stainless Steel
Flexible Channel


Continuous mounting solution for flexible fixtures, 16' or 32' field cuttable lengths

64 #4-40 1/2" screws provided per 16'

Compatible with
NEXUS

SIDE BEND

STND-QCAP-BN-SB




BENDIT Channel
Horizontal Stainless Steel
Flexible Channel

Continuous mounting solution for flexible fixtures, 16' or 32' field cuttable lengths

64 #4-40 1/2" screws provided per 16'

Compatible with
KURV
ZALA

STND-QCAP-BN-SB-W




BENDIT Channel
Horizontal Stainless Steel
Flexible Channel

Continuous mounting solution for flexible fixtures, 16' or 32' field cuttable lengths

64 #4-40 1/2" screws provided per 16'

Compatible with
KURV-BK

MICRO5-BN-SB




BENDIT Channel
Horizontal Stainless Steel
Flexible Channel

Continuous mounting solution for flexible fixtures, 16' or 32' field cuttable lengths

64 #4-40 1/2" screws provided per 16'

Compatible with
ANYBEND
WALA

2 COLOR




Stainless Steel

White

Black
(Available for
KURV-BK only)


TOP VIEW OF UP/DOWN BEND



TOP VIEW OF SIDE BEND



SIDE VIEW OF UP/DOWN BEND



SIDE VIEW OF SIDE BEND



© 2025 QTL. All rights reserved | 155 Hill St. Milford, CT 06460 | 203-367-8777 | sales@QTL.lighting | QTL.lighting

Specification subject to change. **Rev-03-11-25**

BENDIT








Installation Instructions

Mounting Method

- Up/Down Bend (page 2)
- Side Bend (page 3)

COMPONENTS & HARDWARE

Alternate screw lengths can be used in installation as long as the screw diameter size is consistent with the included screw diameter size


SEAMLESS MOUNTING CHANNEL			
STND-QCAP-BN-UD	**STND-QCAP-BN-UD-S**	**MICRO5-BN-UD**	**MICRO5-BN-UD-S**
 Vertical Flexible Channel **Included** • #4-40 1/2" screws (64 screws for every 16') • Up/down bend	 Vertical Flexible Channel **Included** • #4-40 1/2" screws (64 screws for every 16') • Up/down bend	 Vertical Flexible Channel **Included** • #4-40 1/2" screws (64 screws for every 16') • Up/down bend	 Vertical Flexible Channel **Included** • #4-40 1/2" screws (64 screws for every 16') • Side bend
STND-QCAP-BN-SB	**MICRO5-BN-SB**	**STND-QCAP-BN-SB-W**	
 Horizontal Flexible Channel **Included** • #4-40 1/2" screws (64 screws for every 16') • Side bend	 Horizontal Flexible Channel **Included** • #4-40 1/2" screws (64 screws for every 16') • Side bend	 Horizontal Flexible Channel **Included** • #4-40 1/2" screws (64 screws for every 16') • Side bend	

© 2026 QTL. All rights reserved | 155 Hill St. Milford, CT 06460 | 203-367-8777 | sales@QTL.lighting | QTL.lighting

BENDIT


Installation Instructions

SURFACE MOUNTING METHOD: **UP/DOWN BEND**




Determine the fixture(s) location and positioning on desired surface and arrange the BENDIT channel into the desired shape. Make any necessary reference markings to indicate where the channel is to be secured in place.

NOTE: The bend of the channel cannot exceed the bend of the fixture, Bending past the recommended amount can damage the fixture, Please see Q-CAP fixture bend radius chart or fixture cut sheet



Use #6 tapping screws to make shape desired while not exceeding fixture bend radius. Recommended 1 screw approximately every 3”

NOTE: Screws should be secured all the way down.



Press fit the fixture into the channel until secure.


Q-CAP Fixture Bend Radius			
Fixture	Vertical Bend	Horizontal Bend	Helical Bend
ANYBEND	9"	9"	-
BOXA	6"	-	-
KURV	-	6"	-
KURV-BK	-	10"	-
LUME	6"	-	-
NEXUS	4"	-	4"
WALA	-	6"	-
WAVE	6"	-	-
WURM	6"	-	6"
ZALA	-	6"	-

© 2026 QTL. All rights reserved | 155 Hill St. Milford, CT 06460 | 203-367-8777 | sales@QTL.lighting | QTL.lighting

BENDIT


Installation Instructions

SURFACE MOUNTING METHOD: **SIDE BEND**




Determine the fixture(s) location and positioning on desired surface and arrange the BENDIT channel into the desired shape. Make any necessary reference markings to indicate where the channel is to be secured in place.

NOTE: The bend of the channel cannot exceed the bend of the fixture, Bending past the recommended amount can damage the fixture, Please see Q-CAP fixture bend radius chart or fixture cut sheet



Use #4 tapping screws to make shape desired while not exceeding fixture bend radius. Recommended 1 screw approximately every 3”

NOTE: Screws should be secured all the way down.



Press fit the fixture into the channel until secure.

Q-CAP Fixture Bend Radius			
Fixture	Vertical Bend	Horizontal Bend	Helical Bend
ANYBEND	9"	9"	-
BOXA	6"	-	-
KURV	-	6"	-
KURV-BK	-	10"	-
LUME	6"	-	-
NEXUS	4"	-	4"
WALA	-	6"	-
WAVE	6"	-	-
WURM	6"	-	6"
ZALA	-	6"	-

© 2026 QTL. All rights reserved | 155 Hill St. Milford, CT 06460 | 203-367-8777 | sales@QTL.lighting | QTL.lighting